



Model 612A01

High temperature (up to 500F), industrial charge output accel, 26 pC/g, 10 kHz max frequency response, top exit, 2-pin connector

Installation and Operating Manual

**For assistance with the operation of this product,
contact the PCB Piezotronics, Inc.**

**Toll-free: 800-959-4464
24-hour SensorLine: 716-684-0001
Fax: 716-684-3823
E-mail: imi@pcb.com
Web: www.imi-sensors.com**



Repair and Maintenance

PCB guarantees Total Customer Satisfaction through its “Lifetime Warranty Plus” on all Platinum Stock Products sold by PCB and through its limited warranties on all other PCB Stock, Standard and Special products. Due to the sophisticated nature of our sensors and associated instrumentation, **field servicing and repair is not recommended and, if attempted, will void the factory warranty.**

Beyond routine calibration and battery replacements where applicable, our products require no user maintenance. Clean electrical connectors, housings, and mounting surfaces with solutions and techniques that will not harm the material of construction. Observe caution when using liquids near devices that are not hermetically sealed. Such devices should only be wiped with a dampened cloth—never saturated or submerged.

In the event that equipment becomes damaged or ceases to operate, our Application Engineers are here to support your troubleshooting efforts 24 hours a day, 7 days a week. Call or email with model and serial number as well as a brief description of the problem.

Calibration

Routine calibration of sensors and associated instrumentation is necessary to maintain measurement accuracy. We recommend calibrating on an annual basis, after exposure to any extreme environmental influence, or prior to any critical test.

PCB Piezotronics is an ISO-9001 certified company whose calibration services are accredited by A2LA to ISO/IEC 17025, with full traceability to SI through N.I.S.T. In addition to our standard calibration services, we also offer specialized tests, including: sensitivity at elevated or cryogenic temperatures, phase response, extended high or low frequency response, extended range, leak testing, hydrostatic pressure testing, and others. For more information, contact your local PCB Piezotronics distributor, sales representative, or factory customer service representative.

Returning Equipment

If factory repair is required, our representatives will provide you with a Return Material Authorization (RMA) number, which we use to reference any information you have already provided and expedite the repair process. This number should be clearly marked on the outside of all returned package(s) and on any packing list(s) accompanying the shipment.

Contact Information

PCB Piezotronics, Inc.
3425 Walden Ave.
Depew, NY14043 USA
Toll-free: (800) 828-8840
24-hour SensorLine: (716) 684-0001
General inquiries: info@pcb.com
Repair inquiries: rma@pcb.com

For a complete list of distributors, global offices and sales representatives, visit our website, www.pcb.com.

Safety Considerations

This product is intended for use by qualified personnel who recognize shock hazards and are familiar with the precautions required to avoid injury. While our equipment is designed with user safety in mind, the protection provided by the equipment may be impaired if equipment is used in a manner not specified by this manual.

Discontinue use and contact our 24-Hour Sensorline if:

- Assistance is needed to safely operate equipment
- Damage is visible or suspected
- Equipment fails or malfunctions

For complete equipment ratings, refer to the enclosed specification sheet for your product.

Definition of Terms and Symbols

The following symbols may be used in this manual:



DANGER

Indicates an immediate hazardous situation, which, if not avoided, may result in death or serious injury.

**CAUTION**

Refers to hazards that could damage the instrument.

**NOTE**

Indicates tips, recommendations and important information. The notes simplify processes and contain additional information on particular operating steps.

The following symbols may be found on the equipment described in this manual:



This symbol on the unit indicates that high voltage may be present. Use standard safety precautions to avoid personal contact with this voltage.



This symbol on the unit indicates that the user should refer to the operating instructions located in the manual.



This symbol indicates safety, earth ground.



PCB工业监视和测量设备 - 中国RoHS2公布表

PCB Industrial Monitoring and Measuring Equipment - China RoHS 2 Disclosure Table

部件名称	有害物质					
	铅 (Pb)	汞 (Hg)	镉 (Cd)	六价铬 (Cr(VI))	多溴联苯 (PBB)	多溴二苯醚 (PBDE)
住房	O	O	O	O	O	O
PCB板	X	O	O	O	O	O
电气连接器	O	O	O	O	O	O
压电晶体	X	O	O	O	O	O
环氧	O	O	O	O	O	O
铁氟龙	O	O	O	O	O	O
电子	O	O	O	O	O	O
厚膜基板	O	O	X	O	O	O
电线	O	O	O	O	O	O
电缆	X	O	O	O	O	O
塑料	O	O	O	O	O	O
焊接	X	O	O	O	O	O
铜合金/黄铜	X	O	O	O	O	O
本表格依据 SJ/T 11364 的规定编制。						
O：表示该有害物质在该部件所有均质材料中的含量均在 GB/T 26572 规定的限量要求以下。						
X：表示该有害物质至少在该部件的某一均质材料中的含量超出 GB/T 26572 规定的限量要求。						
铅是欧洲RoHS指令2011/65/ EU附件三和附件四目前由于允许的豁免。						

CHINA RoHS COMPLIANCE


Component Name	Hazardous Substances					
	Lead (Pb)	Mercury (Hg)	Cadmium (Cd)	Chromium VI Compounds (Cr(VI))	Polybrominated Biphenyls (PBB)	Polybrominated Diphenyl Ethers (PBDE)
Housing	O	O	O	O	O	O
PCB Board	X	O	O	O	O	O
Electrical Connectors	O	O	O	O	O	O
Piezoelectric Crystals	X	O	O	O	O	O
Epoxy	O	O	O	O	O	O
Teflon	O	O	O	O	O	O
Electronics	O	O	O	O	O	O
Thick Film Substrate	O	O	X	O	O	O
Wires	O	O	O	O	O	O
Cables	X	O	O	O	O	O
Plastic	O	O	O	O	O	O
Solder	X	O	O	O	O	O
Copper Alloy/Brass	X	O	O	O	O	O

This table is prepared in accordance with the provisions of SJ/T 11364.

O: Indicates that said hazardous substance contained in all of the homogeneous materials for this part is below the limit requirement of GB/T 26572.

X: Indicates that said hazardous substance contained in at least one of the homogeneous materials for this part is above the limit requirement of GB/T 26572.

Lead is present due to allowed exemption in Annex III or Annex IV of the European RoHS Directive 2011/65/EU.

Model Number 612A01		HIGH TEMPERATURE INDUSTRIAL CHARGE ACCELEROMETER		Revision: C ECN #: 53216	
Performance		ENGLISH		SI	
Sensitivity(± 15 %)		26 pC/g		2.6 pC/(m/s ²) [1]	
Frequency Range(+ 10 %)		300 kcpm		5,000 Hz [2]	
Frequency Range(+ 3 dB)		600 kcpm		10 kHz	
Resonant Frequency		1,800 kcpm		30 kHz [3]	
Non-Linearity		± 1 %		± 1 % [4]	
Transverse Sensitivity		≤ 5 %		≤ 5 %	
Environmental					
Overload Limit(Shock)		5,000 g pk		49,050 m/s ² pk	
Temperature Range(Operating)		-65 to +500 °F		-54 to +260 °C	
Temperature Response		See Graph		See Graph	
Enclosure Rating		IP68		IP68	
Electrical					
Capacitance		1,500 pF		1,500 pF [3]	
Insulation Resistance(at 500°F)		> 10 ⁹ Ohm		> 10 ⁹ Ohm [3]	
Insulation Resistance(at room temp)		≥ 0.5 x 10 ¹² Ohm		≥ 0.5 x 10 ¹² Ohm [3]	
Electrical Isolation(Base)		> 10 ⁸ Ohm		> 10 ⁸ Ohm [3]	
Output Polarity		Negative		Negative	
Physical					
Sensing Element		Ceramic		Ceramic	
Sensing Geometry		Shear		Shear	
Housing Material		Stainless Steel		Stainless Steel	
Sealing		Welded Hermetic		Welded Hermetic	
Size (Hex x Height)		7/8 in x 2.12 in		22.2 mm x 53.8 mm	
Weight		2.95 oz		83.6 gm [3]	
Electrical Connection Position		Top		Top	
Electrical Connector		2-Pin MIL-C-5015		2-Pin MIL-C-5015	
Mounting Thread		1/4-28 UNF		No Metric Equivalent	
Mounting Torque		2 to 5 ft-lb		2.7 to 6.8 Nm	
<div><div>CE</div><div><p>Typical Sensitivity Deviation vs Temperature</p></div></div>					
<p>All specifications are at room temperature unless otherwise specified. In the interest of constant product improvement, we reserve the right to change specifications without notice. ICP® is a registered trademark of PCB Piezotronics, Inc.</p>					
<div><div><div><div>Optional versions have identical specifications and accessories as listed for the standard model except where noted below. More than one option may be used.</div><div><div>M - Metric Mount</div><div>Supplied Accessory: Model M081A61 Mounting Stud 1/4-28 to M6 X 1 replaces Model 081A40</div></div></div></div></div>					
<div><div>NOTES:</div><div><div>[1]Conversion Factor 1g = 9.81 m/s².</div><div>[2]1Hz = 60 cpm (cycles per minute).</div><div>[3]Typical value.</div><div>[4]Zero-based, least-squares, straight line method.</div></div></div>					
<div><div>SUPPLIED ACCESSORIES:</div><div><div>Model 081A40 Mounting Stud</div><div>Model ICS-1 NIST-traceable single-axis amplitude response calibration from 600 cpm (10 Hz) to upper 5% frequency</div></div></div>					
Entered: ND		Engineer: NJF		Sales: EGY	
Approved: JS		Spec Number:			
Date: 10/14/2022		Date: 10/14/2022		Date: 10/14/2022	
Date: 10/14/2022		Date: 10/14/2022		13075	
<div><div><div><div>IMI SENSORS</div><div>A PCB PIEZOTRONICS DIV.</div></div><div><div>3425 Walden Avenue, Depew, NY 14043</div></div></div><div><div>Phone: 800-959-4464</div><div>Fax: 716-684-3823</div><div>E-Mail: imi@pcb.com</div></div></div>					

10159


PCB Piezotronics Inc. claims proprietary rights in the information disclosed hereon. Neither it nor any reproduction thereof will be disclosed to others without written consent of PCB Piezotronics Inc.

APPLICATION

NEXT ASS'Y	USED ON	VAR

REVISIONS


REV	DESCRIPTION	ECN	DATE	APP'D
B	REVISED PER ECN	14210	10/14/01	DM 10/21

TOP VIEW OF
CONNECTOR

CONNECTOR
5/8-24 UNEF-2A
2-PIN (MIL-C-5015)

7/8(22) HEX

1/4-28 UNF-2B
X .29(7.4) ▽



2.12(53.8)

Ø.870(Ø22.1)
TYP

UNLESS SPECIFIED TOLERANCES

DIMENSIONS IN INCHES	DIMENSIONS IN MILLIMETERS (IN PARENTHESIS)
DECIMALS XX ±.01	DECIMALS XX ±0.3
XXX ±.005	XXX ±0.13
ANGLES ±2 DEGREES	ANGLES ±2 DEGREES

FILLETS AND RADII
.003 - .005

FILLETS AND RADII
(0.07 - 0.13)

DRAWN	4/18	1/4 26.0	MFG	P.L.	10/24/01
CHK'D	DM	10/26/01	ENGR	U.S.	11/16/01
APP'D	MA	11/2/01	SALES	ECN	11/16/01

TITLE
OUTLINE DRAWING
MODEL 612A01, 322M12
CHARGE SENSOR

PCB PIEZOTRONICS
3425 WALDEN AVE. DEPEW, NY 14043
(716) 684-0001 EMAIL: SALES@PCB.COM

CODE
IDENT. NO.
52681

DWG. NO.

10159

SCALE: 1.33 :1 SHEET 1 OF 1

DD011 REV. B 03/13/98