

Model 076A30

Connector kit (includes (1) Model 076A25 tool & (20) 076A05 10-32 plug Installation and Operating Manual

For assistance with the operation of this product, contact PCB Piezotronics, Inc.

Toll-free: 800-828-8840 24-hour SensorLine: 716-684-0001

> Fax: 716-684-0987 E-mail: info@pcb.com Web: www.pcb.com







Repair and Maintenance

PCB guarantees Total Customer Satisfaction through its "Lifetime Warranty Plus" on all Platinum Stock Products sold by PCB and through its limited warranties on all other PCB Stock, Standard and Special products. Due to the sophisticated nature of our sensors and associated instrumentation, field servicing and repair is not recommended and, if attempted, will void the factory warranty.

Beyond routine calibration and battery replacements where applicable, our products require no user maintenance. Clean electrical connectors, housings, and mounting surfaces with solutions and techniques that will not harm the material of construction. Observe caution when using liquids near devices that are not hermetically sealed. Such devices should only be wiped with a dampened cloth—never saturated or submerged.

In the event that equipment becomes damaged or ceases to operate, our Application Engineers are here to support your troubleshooting efforts 24 hours a day, 7 days a week. Call or email with model and serial number as well as a brief description of the problem.

Calibration

Routine calibration of sensors and associated instrumentation is necessary to maintain measurement accuracy. We recommend calibrating on an annual basis, after exposure to any extreme environmental influence, or prior to any critical test.

PCB Piezotronics is an ISO-9001 certified company whose calibration services are accredited by A2LA to ISO/IEC 17025, with full traceability to SI through N.I.S.T. In addition to our standard calibration services, we also offer specialized tests, including: sensitivity at elevated or cryogenic temperatures, phase response, extended high or low frequency response, extended range, leak testing, hydrostatic pressure testing, and others. For more information, contact your local PCB Piezotronics distributor, sales representative, or factory customer service representative.

Returning Equipment

If factory repair is required, our representatives will provide you with a Return Material Authorization (RMA) number, which we use to reference any information you have already provided and expedite the repair process. This number should be clearly marked on the outside of all returned package(s) and on any packing list(s) accompanying the shipment.

Contact Information

PCB Piezotronics, Inc. 3425 Walden Ave. Depew, NY14043 USA Toll-free: (800) 828-8840

24-hour SensorLine: (716) 684-0001 General inquiries: info@pcb.com Repair inquiries: rma@pcb.com

For a complete list of distributors, global offices and sales representatives, visit our website, www.pcb.com.

Safety Considerations

This product is intended for use by qualified personnel who recognize shock hazards and are familiar with the precautions required to avoid injury. While our equipment is designed with user safety in mind, the protection provided by the equipment may be impaired if equipment is used in a manner not specified by this manual.

Discontinue use and contact our 24-Hour Sensorline if:

- Assistance is needed to safely operate equipment
- Damage is visible or suspected
- Equipment fails or malfunctions

For complete equipment ratings, refer to the enclosed specification sheet for your product.

Definition of Terms and Symbols

The following symbols may be used in this manual:



DANGER

Indicates an immediate hazardous situation, which, if not avoided, may result in death or serious injury.



CAUTION

Refers to hazards that could damage the instrument.



NOTE

Indicates tips, recommendations and important information. The notes simplify processes and contain additional information on particular operating steps.

The following symbols may be found on the equipment described in this manual:



This symbol on the unit indicates that high voltage may be present. Use standard safety precautions to avoid personal contact with this voltage.



This symbol on the unit indicates that the user should refer to the operating instructions located in the manual.



This symbol indicates safety, earth ground.



PCB工业监视和测量设备 - 中国RoHS2公布表

PCB Industrial Monitoring and Measuring Equipment - China RoHS 2 Disclosure Table

有害物 质								
铅 (Pb)	汞 (Hg)	镉 (Cd)	六价铬 (Cr(VI))	多溴 联苯 (PBB)	多溴二苯醚 (PBDE)			
0	0	0	0	0	0			
Х	0	0	0	0	0			
0	0	0	0	0	0			
Х	0	0	0	0	0			
0	0	0	0	0	0			
0	0	0	0	0	0			
0	0	0	0	0	0			
0	0	Х	0	0	0			
0	0	0	0	0	0			
Х	0	0	0	0	0			
0	0	0	0	0	0			
Х	0	0	0	0	0			
Х	0	0	0	0	0			
	O X O O O O X X O X X X	田 (Pb) (Hg) (Hg) (Hg) (Hg) (Hg) (Hg) (Hg) (Hg	铅 (Pb) (Hg) (Cd) (Cd) (Cd) (Hg) (Cd) (Cd) (Cd) (Cd) (Cd) (Cd) (Cd) (Cd	田(Pb) 表 (Hg) (Cd) 大价铬(Cr(VI)) の の の の の の の の の の の の の の の の の の	報(Pb) 表(Hg) (Cd) 六价铬 (Cr(VI)) 多溴联苯 (PBB) 0 0 0 0 X 0 0 0 0 0 0 0 X 0 0 0 0 X 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 X 0 0 0 0 X 0 0 0 0 X 0 0 0 0 X 0 0 0 0 X 0 0 0 0 X 0 0 0 0 X 0 0 0 0			

本表格依据 SJ/T 11364 的规定编制。

O:表示该有害物质在该部件所有均质材料中的含量均在 GB/T 26572 规定的限量要求以下。

X:表示该有害物质至少在该部件的某一均质材料中的含量超出 GB/T 26572 规定的限量要求。

铅是欧洲RoHS指令2011/65/EU附件三和附件四目前由于允许的豁免。

CHINA ROHS COMPLIANCE

Component Name	Hazardous Substances							
	Lead (Pb)	Mercury (Hg)	Cadmium (Cd)	Chromium VI Compounds (Cr(VI))	Polybrominated Biphenyls (PBB)	Polybrominated Diphenyl Ethers (PBDE)		
Housing	0	0	0	0	0	0		
PCB Board	Х	0	0	0	0	0		
Electrical Connectors	0	0	0	0	0	0		
Piezoelectric Crystals	Х	0	0	0	0	0		
Ероху	0	0	0	0	0	0		
Teflon	0	0	0	0	0	0		
Electronics	0	0	0	0	0	0		
Thick Film Substrate	0	0	X	0	0	0		
Wires	0	0	0	0	0	0		
Cables	Х	0	0	0	0	0		
Plastic	0	0	0	0	0	0		
Solder	Х	0	0	0	0	0		
Copper Alloy/Brass	Х	0	0	0	0	0		

This table is prepared in accordance with the provisions of SJ/T 11364.


Lead is present due to allowed exemption in Annex III or Annex IV of the European RoHS Directive 2011/65/EU.

O: Indicates that said hazardous substance contained in all of the homogeneous materials for this part is below the limit requirement of GB/T 26572.

X: Indicates that said hazardous substance contained in at least one of the homogeneous materials for this part is above the limit requirement of GB/T 26572.




Model 076A30 Microdot Connector Kit




Connector Assembly Procedure

1. Slide strain relief, pin protector, coupling nut, and ferrule over cable jacket.



2. Strip cable to dimension shown in figure below.




Note: For assembly to cables with "Mini--Noise" coating, Mini--Noise coating must be removed from surface of cable dielectric as follows:

Painted Coatings: Wipe off dielectric surface with a dry cloth. Wipe again using paint thinner or trichloroethane. Do not immerse cable in solvent.


Tape or Fused Coatings: Remove with sandpaper, file, or scraping action of razor blade. Do not damage dielectric.

PCB PIEZOTRONICS


3. Place jerk ring, slotted end first, over the shield. The slotted end butts against the end of the jacket. Squeeze the ring snugly around the shield. Squeeze the slotted end of the ring to a slight taper. Use suitable pliers or Tyco Electronics Corporation assembly tool (Part Number 4-1532129-0).




4. Unbraid shield wires and cut close to jerk ring.



5. Trim end of cable and strip dielectric to dimensions shown in figure below. If inner conductor is stranded, it must be tinned.




6. Slip Teflon® insulator over inner conductor and dielectric until insulator is against shield wires. .







7. Hold ferrule in one hand. With the other hand, push on insulator until jerk ring and part of the insulator start inside the ferrule.



8. Slide coupling nut over ferrule. Screw coupling nut to Part II of assembly tool (**Model 076A25**) until fully seated.




9. Insert contact pin, with barbed end out, in small hole at the end of Part I. Screw into Part II as far as possible, forcing contact pin completely into insulator. Remove Part I and Part II.





10. Position the pin protector behind the coupling nut. Bring the strain relief up and snap it over groove in ferrule body.



This completes assembly.

Document Number: 51208 REV. NR



3425 Walden Ave, Depew, NY 14043-2495 USA **PCB® toll-free** 800-828-8840 **24-hour SensorLine** 716-684-0001 FAX 716-684-0987 E-mail info@pcb.com Website www.pcb.com

ISO 9001 CERTIFIED

© 2000 PCB Group, Inc. In the interest of constant product improvement, specifications are subject to change without notice. Sensor Line is a service mark of PCB Group, Inc. PCB is a registered trademark of PCB Group, Inc. All other trademarks are property of their respective owners.